




# Toshiba Satellite C55-C5268 Battery Replacement

This guide will show you how to properly remove the battery of your Toshiba Satellite.

Written By: Greg Smith



## INTRODUCTION

The battery of the Toshiba Satellite is located on the bottom of the laptop, near where the screen attaches to the base. It is held in place by two Phillips head screws which need to be removed in order to remove the battery. The iFixit toolkit size PH1 bit will fit.



### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-


## Step 1 — Battery



- Unplug and power off the laptop.

⚠ Opening the inside of the laptop before it is completely off poses safety risk of electric shock.


## Step 2



- Unscrew the two 9.0mm screws holding the battery in place using a #1 Phillips screwdriver.



## Step 3



- Grab the battery and pull it away from the laptop to remove it.
- ⓘ This doesn't require a lot of effort, so you don't have to pull too hard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 12:16:43 AM.